

Step 6: Again, go to the Plant section and add the device by scanning the QR/Serial code label on the device. (Fig.2.5)



Figure 2.5

Step 7: Tap on **Offline Devices**. The added device will now appear in the list.(Fig.2.6)



Figure 2.6

Step 8: Select the device from the list and click on the **BT icon**.(Fig.2.7)




Figure 2.7

Step 9: Select the **BT device** according to the device serial number.

Step 10: Enter the **WiFi credentials** to connect it: (Fig.2.8)



Figure 2.8

Then, press **Submit** to complete the setup. The dongle will restart and connect to the desired WiFi.

SHAKTI ENERGY SOLUTIONS LIMITED

Regd. Office, Plot No. 155-156, Sector-III, Industrial Growth Centre, Pithampur, Dist. Dhar, Madhya Pradesh - 454774, India
Contact detail: 07292-410500, Email: info@shaktienergysolution.com

SHAKTI WIFI DONGLE



- Remote Monitoring and Control.
- In-built Data Logger.
- Compatible with WiFi & Bluetooth.

1. Product Appearance




Figure 1

Status Indicator:

LED Type	LED Behaviour	System Status
Pulse LED (RED)	Blink in every second	Working OK
Signal LED (GREEN)	Constant ON	Wi-Fi Connected
Bluetooth LED (GREEN)	Constant ON	Bluetooth Connected

2. Configuration:

Step 1: Connect the "Shakti WiFi dongle" to the main device.

Step 2: Install the **Shakti Grid Tie application** from play store. (Fig.2.1)




Figure 2.1

Step 3: Register by furnishing the required details:(Fig.2.2)




Figure 2.2

Step 4: Click on the **Plant** section from the home screen, then tap on **Add Plant**. (Fig.2.3)




Figure 2.3

Step 5: Provide the required details.(Fig.2.4)




Figure 2.4